

## Installation instructions

# Lavatory Sinks

---

### General Recommendations:

#### Please

Read installation and maintenance instruction thoroughly.  
Be sure to use proper tools and always wear personal safety devices for your protection

#### Warranty

HOUZER stainless steel sinks are produced to highest manufacturing standards using premium grade type-304 stainless steel and are covered by a limited lifetime warranty.  
Carefully follow the step-by-step installation instructions.  
That way you'll ensure complete satisfaction and protect your warranty.

#### Long-Life care

HOUZER Stainless Steel Sinks are easy to keep new looking, longer, with minimal care. For the best results, always rinse with a mild soap and wipe dry after each use. Rub lightly with soft cloth in direction of grain line on a regular basis. To avoid damage to sink surface and discoloration, never use a steel wool or scouring pad.

### Tools and Materials needed:

Tape Measure	Denatured Alcohol	Hacksaw/Jigsaw
Pencil (NOT ink)	Mounting Clips (included)	Screwdriver
Silicone Adhesive Sealant	Eye Protection	Electric Drill
Rags	Ear Protection	

Be sure to use proper tools and always wear personal safety devices for your protection.

---

## Installation Instructions

**Please carefully read complete instructions before beginning installation.**

1. Unpack the new sink and check the contents of the materials supplied: (1) sink, Mounting brackets, cutout template.
2. Supplied cutout template provides two installation options.
  - A. Topmount (Drop-in) installation
  - B. Undermount installation
3. Place the template in desired position on countertop, locating center of the bowl over cabinet and faucet holes.
4. Trace the outline of the template and cut countertop along the inside of the line using appropriate tools. Template is for guide only. Use physical sink to ensure accurate cutout opening. Attach faucet and drain fitting as necessary at this point according to the mfr's instructions.

5. Topmount (drop-In ) Installation (Figure 1)  
Apply adhesive caulk sealant (not furnished) around the underside of the rim. Place the sink carefully, align and press firmly around perimeter of the sink rim.  
Allow sealant to set before proceeding.




Figure 1

6. Undermount Installation (Figure 2)
  - 6-1. Locate and drill holes on the underside of the countertop, approximately 1" from edge of the sink rim to be installed. Loosely attach mounting brackets to the underside of the countertop parallel to the cutout opening. (Depending on the countertop materials, correct type of fasteners may be recommended by your installer or supplier) (Figure 3)




Figure 2

- 6-2 Apply adhesive caulk sealant (not furnished) around the topside of the rim. Allow sealant to set before proceeding. Place the sink from the underside of the countertop carefully, align and press firmly.




Figure 3

- 6-3 Turn bent end of mounting bracket to snug over the sink rim and tighten fasteners. (Figure 4)




Figure 4

---

## 7. Countertop Installation (Vessel sink) (Figure 5)

7-1. Prepare countertop by drilling a 1-3/4" diameter drain hole at desired location. (Figure 6)

7-2. Position lavatory sink on countertop as shown. Secure lavatory to the countertop by installing drain through drain hole. (Figure 7)




Figure 5




Figure 6




Figure 7

## 8. Install waste system according to the mfr's instructions.

Do not over tighten screw. Wipe off excess sealant. Install waste system to drain according to mfr's instructions and check leakage

## Lifetime Limited Warranty

HOUZER stainless steel sinks are produced to the highest manufacturing standards and are covered by a limited lifetime warranty that protects the original purchaser against any defects in materials and workmanship under normal use. If upon determination by HOUZER that the sink is defective, HOUZER will replace without charge, with an equivalent sink or refund, will be sent to the original purchaser that it has been used in a residential application and installed, used and maintained according to the instructions supplied with the sink, and not damaged due to abuse, misuse or negligence. This warranty will not cover any labor charges incurred in installation, removal, replacement or repair, transportation cost or any consequential damages, which might be caused by the product. HOUZER shall not be liable in case of;

- Improper installation or modification of original product.
- Damages resulting from abuse, such as scratches by dropping heavy objects into the sink
- Scratches resulting from scrubbing with steel wool, abrasive pads or cleaners
- Improper application such as exposure to corrosive chemicals, or photographic solutions
- Any commercial application

If the original purchaser finds a defect in material or workmanship, please contact HOUZER Warranty Service, 2605 Kuser Road, Hamilton, NJ 08691. Please include proof of purchase or sales receipt. The law in some states may expand or modify this warranty. This warranty supersedes all other warranties, expressed or implied.

---

## Care and Maintenance

### ALWAYS

- Clean everyday by thoroughly rinsing with a mild soap and warm water and wipe dry.
- Rub lightly with a soft cloth in the direction of grain lines on a regular basis for additional preventive cleaning.
- Keep the sink free of any standing water as this can cause a buildup of mineral deposit, which can affect the appearance of your sink.
- Any stubborn stains should be removed by scrubbing in the direction of the grain with a mild abrasive such as Comet.
- Always rinse the sink after using any cleaning agent and wipe dry.  
Clean any mineral deposits built up over time with a mild solution of vinegar and water followed by a thorough flushing with water.
- Remove any scratches with a Scotch-Brite pad and cleaning agent rubbing in the direction of the grain. NOT RECOMMENDED FOR MIRROR FINISH.

### NEVER

- Leave water spots, steel cookware or utensils in the sink for lengthy periods; iron particles often develop rust spots in the stainless steel surface.
- Use a steel wool or scoring pad as it damages the sink surface and causes discoloration.
- Let household cleaning agents or bleach sit in your sink for long periods of time as this may ruin the finish of your sink.
- Leave rubber mats, sponges or cleaning pads in the sink overnight as this will trap water and could stain and discolor the sink surface.
- Use any drain cleaning products containing sulfuric or hydrochloric acid as this will attack the sink. Silver cleaners can also contain acids that will damage the sink surface.
- Use the inside of the sink as a cutting surface.

**TYPE304**  
PREMIUM STAINLESS STEEL

**SpecPlus**  
EDGE  
The Stronger Edge You Can Buy

**StoneGuard**  
UNDERCOAT PROTECTION

**SUPER**  
**SILENCER**

**Lifetime**  
Warranty

**UPC**

**SP**  
US

ASME A112.19.3-2000